



Bulletin Number: 1510

### **Buckeye Wood Floor Painting Instructions**

\*Proper prep procedures (located on Coliseum 100 and Arena 50 Catalog Sheets) are to be followed if painting over Buckeye Reflections sealers.

\*If painting during a screen and recoat, be sure to abrade painted areas with a dry 3M SPP Pad and tack before further painting for adhesion.

### **Buckeye Wood Floor Painting Instructions**

1. After screening and cleaning floor, allow to dry thoroughly.
2. Using "Blue Painters Tape", tape off lines to be repainted. Paint the whole line to ensure consistent color (2 thin coats are better than 1 thick coat).
3. Solvent-Based Paints: Ace Indoor/ Outdoor Rust Stop, Benjamin Moore Impervo Alkyd High Gloss Metal & Wood Enamel, Sherwin Williams Industrial & Marine Enamel, MAB Rust-O-Lastic High Gloss Alkyd, Porter Glyptex Urethane Enamel, Devco Devguard Alkyd Industrial Gloss enamel, 1 Shot Sign Painters' Lettering Enamel.
4. Water-Based Paints: Sherwin Williams Industrial & Marine Coatings DTM Acrylic, Benjamin Moore Impervex Latex Hi-Gloss, Ace Royal Interior/ Exterior Hi-Gloss, PPG Pitt Tech DTM Acrylic, Glidden Interior/ Exterior Premium Paint.
5. After painting, pull the tape before paint is dry.
6. Allow paint to dry 24 to 48 hours with good ventilation (some dark paints may take up to 5 days or longer).
7. Buff paint with a 3M SPP Pad (3M Surface Prep Pad) to **TOTALLY** roughen and dull the paint before coating the gym floor.

Issued: 9/22/2010  
Supersedes:

## **Buckeye International, Inc.**

2700 Wagner Place • Maryland Heights • MO 63043 • USA • 314.291.1900  
[www.buckeyeinternational.com](http://www.buckeyeinternational.com)